



# MiCRO NOX

ULTRALIGHT NO<sub>X</sub> MONITOR
FOR AIRBORNE MEASURING IN PPB RANGE

## MiCRO NOx

# REVOLUTIONIZING MOBILE NO<sub>x</sub> ANALYSIS

In the pursuit of environmental sustainability, understanding and controlling air pollutants like nitrogen oxides ( $NO_x$ ) is crucial. The MiCRO NOx mobile  $NO_x$  Analyzer is a revolutionary tool that empowers technical staff and researchers to actively monitor and significantly reduce air pollution. With its advanced features and unparalleled portability, the MiCRO NOx is set to transform the landscape of air quality monitoring and environmental research.



#### Broadening horizons in air quality monitoring

The applications of the MiCRO NOx span critical areas in environmental and climate research, where understanding the distribution and concentration of  $NO_x$  is essential for assessing pollution sources and impacts. Its mobility allows for unprecedented studies of urban air quality, offering insights into pollution hotspots and the effectiveness of mitigation strategies in real-time.

In environmental and climate research, the MiCRO NOx supports in-depth studies on the interactions between pollutants and climate variables, enhancing our understanding of their broader environmental impacts. For urban air quality monitoring, it provides valuable data that can guide policy-making, urban planning and public health initiatives, helping to create healthier, more sustainable urban environments.

### Technical progress for on-the-go precision

The MiCRO NOx stands out with its ultralight design, making it the ideal solution for mobile use. Its capacity for continuous, real-time measurements allows for the detailed tracking of  $NO_x$  levels across different environments and conditions. With autonomous operation, a built-in GPS module, and meteorological sensors, the MiCRO NOx provides comprehensive data on the go, capturing the nuances of air quality in real-time and space.

Automatic calibration ensures that the device maintains its accuracy without the need for complex setup procedures, while its fast measurement capabilities mean that data is not just timely but also highly relevant. Adhering to standard procedures, the MiCRO NOx guarantees reliable and comparable results, making it a trusted tool in the field of air quality analysis.





## **Empowering users - unmatched convenience and reliability**

The MiCRO NOx is more than a technological innovation; it is a user-centric device, designed to simplify the task of air quality monitoring. Its mobile nature opens up new possibilities for on-site analysis, providing immediate insights that can inform quick decisions and actions. The simplicity of its operation and field calibration means that it can be used effectively by a wide range of personnel, from field researchers to environmental consultants, without the need for extensive training.

Environmental institutions and measuring stations can leverage the MiCRO NOx's capabilities to expand their monitoring networks, covering more ground with greater accuracy and less effort. By bringing the laboratory to the field, the MiCRO NOx paves the way for more dynamic and responsive environmental monitoring strategies.





#### A leap forward in environmental responsibility

The MiCRO NOx analyzer represents a significant advancement in our ability to monitor and understand air pollution, offering a blend of technical excellence, user-centric design, and wide-ranging applicability. Its introduction marks a pivotal moment in environmental monitoring. It provides us with the necessary tools to confidently tackle one of the most pressing challenges of our time: air pollution!

With the MiCRO NOx, industries, researchers and environmental advocates are equipped with a powerful ally in the fight for cleaner air and a healthier planet. It's not just about tracking pollutants; it's about empowering change-makers with the data and insights needed to forge a cleaner, more sustainable future.

Choose MiCRO NOx: mobilizing data, clearing the air for tomorrow.

#### **Specifications**

Detection technique: Chemiluminescence, using luminol reaction

Detection limit: ~1ppb

Linear range: <2ppb to 500ppb

Noise: 2% full scale

Time resolution: <1sec

Sample gas: 0°C to 40°C

Calibration: Automatic, using gas standard

Reagent consumption: <100µL/min

Operation data visualization: Graphic user interface (7" touch panel

Data storage: Internal, download via USB

Weight and dimension: Flight unit <2kg (diameter: 21cm. height: 20cm)

Ground control 5kg (whd: 35cm × 20cm × 30cm)

Power requirements: 12V to 24VDC, max. 700mA



ZF4186201RE5

#### Supported by:



on the basis of a decision by the German Bundestag

#### **AERO-LASER GmbH**

Unterfeldstr. 12
D-82467 Garmisch-Partenkirchen
Germany

Tel: +49-8821-94386-0 info@aero-laser.de www.aero-laser.de



Follow us on



